

Electric Quickie Saw



Specs

Accepts a 14" blade (not included)

We sell or rent diamond blades and also sell abrasive blades (wear away as you cut)

With a 14" blade, you will get about 4" of depth from your cut

You CANNOT use water with this saw. It is dangerous and it ruins the brushes in the saw. If you ignore this and use water, you agree to purchase the saw.

If you need to use water while cutting and cannot use a gas saw, we do rent a pneumatic quickie saw that will run off a large compressor.